

PULL OUT PILOT CHUTE PACKING INSTRUCTIONS



1. A strip of binding tape has been provided at the top of the pilot chute for cocking purposes. See Centerline Collapsible Pilot Chute Instructions.

Note: Pull-out bridle lines don't have a check window.



2. After placing the main canopy in the container, remove all twists in the bridle, and check that the pilot chute is cocked.



3. Prior to closing flaps 1 and 2, insert the handle as shown.



4. Neatly gather bridle line.

PULL OUT PILOT CHUTE PACKING INSTRUCTIONS



5. Place bridle line under pilot chute. Ensure base of pilot chute is to the bottom right side of container.



6. Lay the pilot chute's canopy fabric over top of the mesh and close flaps 1 and 2.
Important: Make sure the pull-out lanyards tab is to the bottom right corner as shown.



7. Close flaps 3 and 4. Remove pull-up cord.
Important: Make sure the pull-out lanyard's tab is free to pop down easily as shown.



8. Tuck pull-out lanyard and tab under the side flap and close pin cover.

Note: If you have never packed or jumped with this type of system, a test pull on the ground is advisable.

Call Mirage Systems if in doubt.