

# Wrap-It Link™ Assembly Instructions



1. Confirm continuity,  
insert link through lines...



2. Wrap-It™ through riser...



3. Wrap-It™ through lines  
and riser a **second** time...



4. Wrap-It™ through lines  
and riser a **third** time...



5. Place end through loop  
holding ring...



6. Lock running end by  
pulling ring through loop.



7. Pull to tighten knot...



8. Pull lines and riser to  
evenly distribute 3 wraps.



9. Rotate ring into riser  
and shape link as shown  
above.

**Precision**  
aerodynamics, inc.

727 Rankin Ave. N., P. O. Box 386, Dunlap, TN 37327, USA  
423-949-4688 423-949-5174 (fax)  
[www.aerodynamics.com](http://www.aerodynamics.com)