

STRONG ENTERPRISES

**11236 Satellite Blvd.
Orlando, FL 32837 USA**

Tel 407-859-9317

Fax 407-850-6978

E-Mail: sales@StrongParachutes.com

website: www.StrongParachutes.com

THE PARACHUTE COMPANY WITH IMAGINATION

Addendum to Para-Cushion Owners Manual
PN# 510048, Rev. B (Feb. 1996)
for packing the Strong Enterprises

<p>Squadron Seat Pack PN 1045-T with Military 28 Ft. C-9 Canopy.</p>
--

Replace steps 8-12 on page 12 of the manual with the following:

at the top corner of the side flap (Illustration 28.3).

8. SKIRT PLACEMENT: Slide the skirt straight in towards the lower left corner, leaving it about 2" from the bottom.

9. Make an S fold 12 inches from the skirt, folding down towards and filling the lower left corner. Fill the remaining left side of the pack by stacking the canopy on its side between the lines and up towards the top of the container. (The canopy goes up, down (fill the corner) up, stacked on its side).

10. CLOSE LEFT SIDE FLAP: Pull up the temporary locking loops and pass them through the two middle grommets on the left flap and secure with temporary pins. Mate the Velcro located

11. ACCORDION FOLD, RIGHT SIDE: Route the canopy across the top of the pack, beyond the lines stows. Do not stack the folds on top of each other on the right side as is done on the left side. Turn the folds 90 degrees and stack them on their side towards the center of the container filling in the corners as you go.

12. Spread the apex out flat and lay it on top of the folds routing the bridle to the center of the pack, then outside between the container flaps. Pass the pull up cords through the two middle grommets on the right flap and secure with temporary pins (Illustration 28.4).