

### Hurricane trim settings

Size	95/105	120	135	150	170
A	2730	2892	3067	3232	3442
A-B	48	51	54	57	60
A-C	187	200	212	222	238
A-D	375	397	422	445	473
A1	2743(+13)	2905(+13)	3082(+15)	3248(+16)	3458(+16)
A1-B1	70	73	76	83	86
A1-C1	225	241	248	267	286
A2	2740(+10)	2899(+7)	3073(+6)	3242(+10)	3451(+9)
A2-B2	64	67	73	76	79
A2-C2	187	200	213	222	238
A2-Ust 1	321	359	365	381	406
A2-Ust 2	248	276	283	295	324
A2-Ust 3	213	238	219	257	273
A2-Ust 4	181	200	206	216	232
LST	2111	2245	2372	2496	2657
Brk-Toggle	394	413	432	454	483

**NOTE: All dimensions in mm.**